

# MiiCraft Maintenance Manual

## Hyper/ Prime

Version 1.0



### Specification

Item	Prime 150	Prime 110	Hyper 125	Hyper 80	Hyper 50
Area(mm)	150x84.5x120	110x62x120	125x70x120	80x45x120	57x32x120
XY Res.	55 $\mu\text{m}$	40 $\mu\text{m}$	65 $\mu\text{m}$	41.5 $\mu\text{m}$	30 $\mu\text{m}$
Z-Layer Resolution	5 $\mu\text{m}$ to 500 $\mu\text{m}$				
Wavelength(LED)	385/405 nm wavelength are available for all configurations				
UI & Connectivity	Touch screen / Ethernet, USB				

The key components of the machine or 3D printer needs some maintenance for having smooth performance. Additive manufacturing uses key components of mechanical & electrical systems. Mechanical components need some regular & yearly maintenance for having better performance & long life. The common error & their maintenance method of MiiCraft 3D printer are provided in this manual.

**Note - Unplug the power cable of the printer to start the maintenance procedure.**

## Contents

- 1) Z Motor Maintenance \_\_\_\_\_ Page No 3
- 2) Picker Maintenance \_\_\_\_\_ Page No 4
- 3) Teflon & Holding Glass Maintenance \_\_\_\_\_ Page No 5
- 4) Common & frequently performed practices \_\_\_\_\_ Page No 7
- 5) Prime Series Teflon Maintenance \_\_\_\_\_ Page No 8


## 1) Z Motor Maintenance :-

Check Method :-

- Using Computer Interface
- Using Touch panel

Procedure :-

- Take Z motor downward by using touch panel or computer interface.
- When platform touches bottom limit sensor, add sewing machine oil on the guide pin shaft's & central screw.
- The amount of the oil should not exceed 0.5ml



## 2) Picker Maintenance

- Clean picker surface with Alcohol & dust free wiper



- Clean clamping area from both sides frequently to avoid resin addition on the picker holder



**3) Teflon & holding Glass Maintenance (Prime & Hyper Series)**

- Remove all of the failure parts from the tank




- Clean the rear side area with dust free wiper (Use alcohol if needed)




**MiiCraft 3D Production System >> An important step in making a better world**

- Check the holding glass & keep the surface clean every time



- Clean all spots & resin ink from the glass surface



**4) Common & frequently performed practices**

The following tables present maintenance and repair guidelines connected with each section of the MiiCraft Hyper & Prime series printers, together with specific check points, necessary activities and their frequency.

Sr. No.	Activity	Frequency
1	Cleaning & checking the machine & interior Surroundings	Before Every Print
2	Cleaning Picker Surface	Before Every Print
3	Cleaning teflon glass	After change of teflon or print failure
4	Change of Teflon	After 20 prints
5	Resin Mixing	Before Every Print
6	Check for printing residuals in the resin tank	After Printing / Must check if print failure occurs
8	Cleaning Tank	After Print Failure
9	Restart / Shut Down	Shut Down the printer if there's no use
10	Z Motor lubrication	If noise in Z motor run


5) **Prime Series Change of Teflon Film**

Before performing change of teflon film, remove the resin & failed printing residuals inside the tank & clean the internal surface

- New teflon module will be provided in following format




- Place the teflon tank upside down & remove 16 screws (M3X6) highlighted in red circles using screw driver






- Separate the teflon film & film holder from the tank module




- Add new teflon & telon holder on the tank as shown in following Image



## MiiCraft 3D Production System >> An important step in making a better world

- Add 16 screws provided with the teflon film module on the tank surface  
Screw should be inserted in following order 1 to 16



- We suggest the use of **Stanley 65-167** screw driver should be done while changing teflon film module on prime series printers

**Specifications :-**

**Philips Tip Type**

**Tip size : 2 (Blade: #2)**

Thanks for reading carefully,

Team MiiCraft.